

RECOMMENDED FILTER SCHEDULE

	PART#	DESCRIPTION	SCHEDULE
	000263 003006 007241	HP filter assembly includes filter, high pressure filter, and O-ring	Change every 12 months
	003004 051582	Small return filter 2.5"x5", O-ring for housing 013340	Change after first 50 hours of use, then every 12 months
	007364 050291	Large return filter 4"x9", O-ring	Change after first 50 hours of use, then every 12 months
	012052	Current production PSS fan element	Change periodically according to working environment
	007086	Quincy compressor air filter	Change every 12 months
	051241	Vanair RC40 air filter	Change every 12 months
	014695	Donaldson filler breather	Change every 6 months on average
Tours of the second of the sec	019382	Composite tank return filter	Gauge on filter lets you know when to replace it
	020725	Composite tank breather filter	Gauge on filter lets you know when to replace it